

Replacement Faucet Installation Instructions

The connection from the faucet to your Reverse Osmosis System may be different with this replacement faucet than the faucet originally supplied with the Reverse Osmosis System.

Follow the steps below to install the replacement faucet.

1. Turn off water to the Reverse Osmosis system.
2. Loosen faucet hardware and slide faucet up from the countertop.
3. Disconnect all tubing connections from faucet and discard the old faucet and hardware.
4. Snap the o-ring in the groove on the bottom of the ring and slide the monitor ring onto the faucet stud. The monitor ring LED wire must be routed through the sink or countertop hole and through the spacer, if used. Refer to Fig. 1.
5. Snip off about 1/2" length of tubing from both the 1/4" red tubing and the 3/8" black tubing before reattaching to the barbs on the new faucet. See Fig. 2.
6. Work tubing and the faucet stud back down into the mounting hole in the countertop or sink.
7. On the underside of the sink or countertop, install the spacer (if included), plastic bushing, flat washer, and hex nut. Refer to Fig. 1. Slide the large steel washer in place, between the bushing and spacer (if included). Then, tighten the hex nut securely. Make sure that the LED wire is in a position so that it will not be cut, pinched or kinked before tightening the faucet assembly.
8. Thread the tubing connector onto the bottom of the faucet stud. See Fig. 2.
9. Snip off about 1/2" length from the end of the 3/8" blue tubing from the R.O. Push the end of the blue tube into the tubing connector. See Fig. 2.




FIG. 1




FIG. 2